



**Imo Delaval Inc.**

## **INSTRUCTIONS and PARTS LIST**

### **SERIES FPG12LZ-250**

**WARNING**

**READ THIS INSTRUCTION BOOK AND CA-1 BEFORE  
INSTALLATION, OPERATION OR MAINTENANCE**

#### **Instructions FPG12L (R-2)**

This manual now is  
identified as part no.  
SRM00058

**Imo Delaval Inc.**  
**IMO Pump Division**  
P.O. Box 5020  
Airport Road  
Monroe, NC 28110-0527  
U S A

**June 1987**

**ORDERING INSTRUCTIONS**

All correspondence pertaining to renewal parts for the equipment must refer to the instruction book number and should be addressed to the nearest Imo Pump Division Sales Office or representative. See addresses of sales offices listed above.

The handling of renewal orders will be greatly facilitated if the following directions are carefully observed.

1. Give the number of the instruction book.
2. Give the serial number of the machine for which part is desired. This number appears on the name-plate.
3. Designate the desired part by the number and name as listed in this instruction book.
4. Give the drawing number or figure number in which the part is shown. (In the event the part is called out on an unnumbered sketch – the page number on which the sketch appears should be used in lieu of the drawing number as the reference.)

**For Example:**

Instruction Book No. ....A3D-6  
Serial Number .....505629  
Part Number and Name .....063, Power Rotor  
Drawing Number (see item 4 above) .....SF-5377

## FOREWORD

This manual covers the FPG12LZ-250 Series IMO pump. The model of a particular pump may be found on the nameplate.

The FPG12LZ-250 series pumps are equipped with a steel case and rotors, bimetallic housing, high temperature ball bearing and a Borg-Warner Type Q mechanical shaft seal.

## SPECIAL INSTALLATION INSTRUCTIONS

### Mounting

Driver - The unit may be mounted in any position without adversely affecting its performance. It is recommended that the unit be driven direct through a flexible coupling.

Inlet Position - The inlet head may be positioned in increments of 90° from the position shown on the assembly drawing.

Remove cap screws and rotate inlet head to desired position. Replace cap screws and torque to value listed on appropriate assembly drawing.

## OPERATIONAL SAFETY PRECAUTIONS

### Structural Limits

Operating conditions, such as speed, fluid viscosity, inlet pressure, discharge pressure, temperature, filtration, duty cycle, mounting, drive type, etc. are interrelated. Due to these variable conditions, the specific application limitations may be different from that of the structural limitations. This equipment must not be operated without verification that operating requirements are within published capabilities as shown in the appropriate pump data book (available from local IMO Pump Division offices and representatives).

Under no circumstances are the following structural limitations to be exceeded.

Maximum Discharge Pressure - 1100 PSIG Normal - 1400 PSIG Fuel Oil - 3000 PSIG Lube Oil

Maximum Inlet Pressure - 75 PSIG

Maximum Speed - 3600 RPM

## **Disassembly of Pump**

General - Close off suction and discharge piping to pump. Disconnect piping and uncouple pump from its driver. To keep spillage to a minimum during disassembly, drain the pump case. This may be accomplished by removing the drain plug (041) from the inlet head (040).

Step 1 - Remove pump from its base to a convenient and clean working area.

Step 2 - Loosen set screw (045), remove check nut (044), key (043), and the coupling hub from power rotor (018).

Step 3 - Remove cap screws (028) and retainer (027).

Step 4 - Pull power rotor assembly from cover (013). The power rotor assembly consists of parts—power rotor (018), mechanical seal (019), gasket (020), adapter seat (022), pin (023), spacer (024), bearing (026), and truarc retaining rings (025).

### **CAUTION**

**Gasket (020) may be on the adapter seat (022) or the inboard end cover (013).**

Step 5 - Remove inlet head (040) by removing (12) cap screws (030), gasket (011), clamp ring (047), and pin (048).

Step 6 - Remove cover inboard assembly by removing (12) cap screws (030). The inboard cover assembly consists of inboard cover (013), stop (016), two cap screws (017), "O" ring (010), spring pin (014), and bushing (015). Gasket (029) will be on cover (013) or case (001).

Step 7 - Remove two idler rotors (034) and two idler rotor assemblies (031). Idler rotor assembly (031) consists of idler rotor (032) and shoe (033).

Step 8 - Rotor housing assembly can now be removed from the inlet end of the pump. The rotor housing assembly consists of rotor housings (005) and (008), two vent pins (007), spring pin (006), adjusting cap screws (009), two cap screws (039), plate (035), thrust plate (036), two cap screws (037), two spacers (038), and "O" ring (010).

Step 9 - Remove thrust assembly by removing two cap screws (039), two spacers (038), and two cap screws (037) from plate (036).

Step 10 - Remove bushing (015) by removing two cap screws (017), and stop (016) from inboard end cover (013).


Step 11 - To remove the mechanical seal (019) from power rotor (018), remove retaining ring (025) nearest the keyway and remove ball bearing (026) and spacer (024).

Step 12 - Remove retaining ring (025) nearest the mechanical seal, then remove the adapter seat assembly consisting of the seat adapter (022), pin (023), stationary seat, and its "O" ring. Remove the mechanical seal from power rotor (018).

## **Reassembly of Pump**

Inspect and clean all parts before starting reassembly. New "O" rings should be installed whenever the pump is rebuilt.

**NOTE:** All screws and bolts must be installed lubricated with oil and torqued to the values listed on the appropriate assembly drawing. Light lubricating oil should be used to assist pump reassembly. **DO NOT USE GREASE.**



NOTES:  
 1. FOR PART DESCRIPTION SEE LIST OF PART NUMBERS  
 2. TORQUE TO 200 FT. LBS.  
 3. TORQUE TO 25 FT. LBS.  
 4. TORQUE TO 25 INCH LBS.  
 5. WITH OIL.

FPG 12LZ-250

- c. Insert two idler rotor assemblies, consisting of idler rotor (032) and shoe (033), the shoe end first to ride against the thrust plate (036).
- d. Insert two idler rotors (034) into rotor (008) tubular extensions toward the outlet port.

**Step 7** - End Cover Assembly (Step 2)

- a. Place gasket (029) on face of end cover assembly (013). Bolt to case (001) using (12) capscrews (030). Torque to  $200 \pm 10$  feet pounds. Be sure spring pin (014) is engaged in hole in case (001). The end float in the rotor housings should be .010" to .020".

**Step 8** - Assembly of Power Rotor Assembly (Step 1) to End Cover

- a. Install gasket (020) in counter bore in end cover (013).
- b. Insert threaded end of power rotor (018) into end cover (013). Case must be taken not to move gasket (020).
- c. Engage threads of power rotor (018) and idler rotors (034). Slide power rotor toward the suction end and engage idler rotors (032). Continue to slide power rotor (018) toward suction until the seat adapter (022) contacts the gasket (020).
- d. Install bearing retainer (027) with cap screws (028). Torque cap screws to  $20 \pm 2$  feet pounds.

**Step 9** -

- a. Install plug (041) and "O" ring (042) in inlet head (040).
- b. Install coupling hub, key (043), check nut (044), and set screw (045).

PARTS LIST  
 FPG12LZ-250  
 DWG. SF-5584

| Pt. No. | Name                        | Pt. No. | Name                      | Pt. No. | Name                  |
|---------|-----------------------------|---------|---------------------------|---------|-----------------------|
| 001     | Pump Case                   | 017     | Cap Screw (2)             | 033     | Shoe ****             |
| 002     | Plug STHH (2)               | 018     | Power Rotor XX            | 034     | Idler Rotor (2) XX    |
| 003     | "O" Ring (2) X              | 019     | Seal X                    | 035     | Plate                 |
| 004     | Housing Sub Assem. XX       | 020     | Gasket X                  | 036     | Plate XX              |
| 005     | Housing *                   | 021     | Adapter Seat Sub. Assem.  | 037     | Cap Screw (2)         |
| 006     | Spring Pin *                | 022     | Adapter Seat ***          | 038     | Spacer (2)            |
| 007     | Vent Pin (2) *              | 023     | Spring Pin ***            | 039     | Cap Screw (2)         |
| 008     | Housing *                   | 024     | Spacer XX                 | 040     | Inlet Head            |
| 009     | Cap Screw (Adjusting) (2) * | 025     | Truarc Ring (2) X         | 041     | Plug STHH             |
| 010     | "O" Ring (2) X              | 026     | Ball Bearing X            | 042     | "O" Ring X            |
| 011     | Gasket X                    | 027     | Retainer                  | 043     | Key                   |
| 012     | Cover Inb. Sub. Assem.      | 028     | Bolt (4)                  | 044     | Check Nut             |
| 013     | Cover Inb. **               | 029     | Gasket X                  | 045     | St. Screw             |
| 014     | Spring Pin **               | 030     | Cap Screw (24)            | 046     | Clamp Ring Sub Assem. |
| 015     | Bushing XX                  | 031     | Idler Rotor Sub Assem. XX | 047     | Clamp Ring *****      |
| 016     | Stop XX                     | 032     | Idler Rotor ****          | 048     | Spring Pin *****      |

\*Parts make-up housing sub assem. 004

\*\* Parts make-up cover inb. sub assem. 012

\*\*\* Parts make-up adapter seat sub assem. 021

\*\*\*\* Parts make-up idler rotor sub assem. 031

\*\*\*\*\* Parts make-up clamp ring sub assem. 046

All parts marked X make-up a minor repair kit.

All parts marked XX and XX make-up a major repair kit.

All quantities are one except when noted in parenthesis.

**The instructions given herein cover generally the operation and maintenance of subject equipment. Should any questions arise which may not be answered specifically by these instructions, they should be referred to the IMO Pump Division, for further detailed information and technical assistance.**

**This manual cannot possibly cover every situation connected with the operation, adjustment, inspection, test, overhaul and maintenance of the equipment furnished. Every effort is made to prepare the text of the manual so that engineering and design data is transformed into the most easily understood wording. The IMO Pump Division, in furnishing this equipment and this manual, must presume that the operating and maintenance personnel assigned thereto have sufficient technical knowledge and experience to apply sound safety and operational practices which may not be otherwise covered herein.**

**In applications where the IMO Pump Division furnished equipment is to be integrated with a process or other machinery, these instructions should be thoroughly reviewed to determine the proper integration of the equipment into the overall plant operational procedures.**