



**INSTRUCTION MANUAL
AND
PARTS LIST
FOR D12DZ-250 (3215/525)**



WARNING

This Instruction Manual and General Instructions Manual, CA-1, should be read thoroughly prior to pump installation, operation or maintenance.


Manual No. SRM00078


Rev. 0

June 2005


READ THIS ENTIRE PAGE BEFORE PROCEEDING

FOR THE SAFETY OF PERSONNEL AND TO PREVENT DAMAGE TO THE EQUIPMENT, THE FOLLOWING NOMENCLATURE HAS BEEN USED IN THIS MANUAL:

| | | |
|---|---------------|--|
|  | DANGER | Failure to observe the precautions noted in this box can result in severe bodily injury or loss of life. |
|---|---------------|--|

| | | |
|---|----------------|--|
|  | WARNING | Failure to observe the precautions noted in this box can cause injury to personnel by accidental contact with the equipment or liquids. Protection should be provided by the user to prevent accidental contact. |
|---|----------------|--|

| | | |
|----------------|------------------|--|
| CAUTION | ATTENTION | Failure to observe the precautions noted in this box can cause damage or failure of the equipment. |
|----------------|------------------|--|

| | | |
|--|---|---|
| Non compliance of safety instructions identified by the following symbol could affect safety for persons: <div style="text-align: center;"></div> | Safety instructions where electrical safety is involved are identified by: <div style="text-align: center;"></div> | Safety instructions which shall be considered for reasons of safe operation of the pump and/or protection of the pump itself are marked by the sign: <div style="text-align: center;">ATTENTION</div> |
|--|---|---|

| | |
|------------------|--|
| ATTENTION | If operation of this pump is critical to your business, we strongly recommend you keep a spare pump or major repair kit in stock at all times. As a minimum, a minor repair kit (o-rings, gaskets, shaft seal and bearings) should be kept in stock so pump refurbishment after internal inspection can be accomplished. |
|------------------|--|

CONTENTS

| | |
|--|---|
| Safety And Table Of Contents | A |
| A. General Instructions | 1 |
| B. Introduction..... | 1 |
| C. Description of the Equipment..... | 1 |
| D. Pump Model Identification | 2 |
| E. Ordering Instructions | 2 |
| F. Operation | 2 |
| G. Parts List | 3 |
| H. Pump Maintenance | 3 |
| I. Troubleshooting | 4 |
| J. Field and Factory Service and Parts | 4 |
| K. Seal Drawing..... | 7 |
| K. Assembly Drawing | 8 |

| | |
|------------------|--|
| ATTENTION | <i>If operation of pump is critical to your business, we strongly recommend you keep a spare pump or major repair kit in stock at all times. As a minimum, a minor repair kit (o-rings, gaskets, shaft seal and bearings) should be kept in stock so pump refurbishment after internal inspection can be accomplished.</i> |
|------------------|--|


A. GENERAL INSTRUCTIONS

The instructions found herein cover the disassembly, assembly and parts identification of D12DZ-250 pumps.

NOTE: Individual contracts may have specific provisions that vary from this manual. Should any questions arise which may not be answered by these instructions, refer to General Instructions Manual, CA-1, provided with your order. For further detailed information and technical assistance please refer to Imo Pump, Technical/Customer Service Department, at (704) 289-6511.

This manual cannot possibly cover every situation connected with the installation, operation, inspection, and maintenance of equipment supplied. Every effort was made to prepare the manual text so that engineering and design data is transformed into the most easily understood wording. Imo Pump must assume personnel assigned to operate and maintain supplied equipment and apply this instruction manual have sufficient technical knowledge and are experienced to apply sound safety and operational practices which may not be otherwise covered by this manual.

In applications where equipment furnished by Imo Pump is to become part of processing machinery, these instructions should be thoroughly reviewed to ensure proper fit of said equipment into overall plant operational procedures.

| | |
|---|----------------|
|  | WARNING |
| <p>If installation, operation and maintenance instructions are not correctly and strictly followed and observed, injury to personnel or serious damage to pump could result. Imo Pump cannot accept responsibility for unsatisfactory performance or damage resulting from failure to comply with instructions.</p> | |

B. INTRODUCTION

This instruction manual covers D12DZ-250 pumps. This series of pumps has been designed for use in fuel applications requiring high inlet pressure capabilities. The model, and design construction of each pump can be identified by the designator code on the pump nameplate. Definitions of model designators are identified in Figure 1.


C. DESCRIPTION OF EQUIPMENT

D12DZ-250 pumps are positive displacement, rotary screw pumps consisting of two precision bored housing that encloses a driven screw (power rotor) and four intermeshing following screws (idler rotors). These screws, when rotating, form a succession of closures or cavities. As they rotate, fluid is moved axially from inlet port to outlet port in a continuous, uniform flow with minimum fluid pulsation and pump noise.

D. PUMP MODEL IDENTIFICATION

This instruction manual covers the Imo D12DZ-250 pump. The model of each pump is identified on pump nameplate.

Figure 1 – Model Designation



E. ORDERING INSTRUCTIONS

When corresponding with Imo Pump regarding D12DZ-250 pumps, refer to pump nameplate, this instruction manual, and assembly drawing as instructed below:

1. From pump nameplate, record pump model number, serial number and manufactured date.
2. Record instruction manual number, revision and date.
3. From the assembly drawing and/or parts list (Table 2) in manual, provide IDP number(s) and names for replacement part(s).
4. Give above information to your Imo Representative.

F. OPERATION

F.1 LIQUID LIMITATIONS

Never operate on water. The pump is designed for liquids having general characteristics of oil.

F.2 OPERATING LIMITS

| CAUTION | ATTENTION |
|---|------------------|
| Operating conditions, such as speed, fluid viscosity, temperature inlet pressure, discharge pressure, filtration, duty cycle, drive type, mounting, etc., are interrelated. Due to these variable conditions, specific application limits may be different from that of operational limitations. Equipment must not be operated without verifying system's operating requirements are within pump's capabilities. | |

Under no circumstances are the following operating limits (specified in Table 1) to be exceeded without specific approval from Imo Pump:

Table 1 – Normal Pump Operating and Structural Limits

| | |
|--|--|
| Maximum Speed | 3600 RPM |
| Viscosity | 1 cSt Minimum – 3000 SSU (650 cSt) Maximum |
| Minimum – Maximum Liquid Temperature | 0 to 250°F (-18 to 121°C) |
| Maximum Inlet Pressure | 150 psig |
| Maximum Discharge Pressure | 2200 psig, Cont. Duty |
| Filtration | (See General Instruction Manual, CA-1) |
| Drive | Direct only |
| Mounting | Foot or Flange mounted in any attitude |


G. PARTS LIST


Table 2 – Pump Parts List

| IDP | QTY | DESCRIPTION | KIT | IDP | QTY | DESCRIPTION | KIT |
|-----|-----|------------------|-----|-----|-----|------------------------|-----|
| 1 | 1 | Case | | 47 | 4 | Bolt | |
| 2 | 1 | Inlet Head | | 48 | 1 | Spacer | XX |
| 4 | 8 | Bolt | | 49 | 1 | Ball Bearing | X |
| 6 | 1 | Stop Pin | XX | 50 | 1 | Discharge Housing | XX |
| 7 | 1 | Dyna Seal | X | 63 | 1 | Power Rotor | XX |
| 8 | 2 | Retaining Ring | XX | 67 | 2 | Plug | |
| 9 | 2 | Gasket | X | 70 | 1 | 90° Elbow (Tube-MNPT) | |
| 21 | 2 | Suction Idler | XX | 71 | 1 | Seal Pipe | |
| 23 | 2 | Idler Cups | XX | 73 | 1 | Pin | XX |
| 24 | 1 | Suction Housing | XX | 74 | 1 | Elbow | |
| 25 | 1 | Seal | X | 75 | 1 | Flare-less connection | |
| 26 | 2 | Tube | XX | 76 | 1 | Nipple | |
| 28 | 2 | O-Ring | X | 77 | 2 | Vent Pin | XX |
| 29 | 1 | Thrust Cage | XX | 78 | 1 | Balance Piston Housing | XX |
| 31 | 1 | Key | | 79 | 1 | Bushing | XX |
| 35 | 2 | Discharge Idlers | XX | 80 | 1 | Idler Stop | XX |
| 38 | 1 | Seal Spacer | | 81 | 1 | Cap screw | |
| 42 | 2 | Retaining Ring | X | 94 | 1 | Gasket | X |
| 43 | 1 | Bearing Retainer | | 100 | 1 | Retainer | XX |
| 46 | 1 | Inboard Cover | | 101 | 1 | Retaining Ring | XX |

X = Minor Repair Kit Items.
 XX = Major Repair Kit Items. (Items marked (X) are included in Major Repair Kit).

H. PUMP MAINTENANCE

| | |
|--|----------------|
|  | WARNING |
| <p>Failure to observe precautions while installing, inspecting, and maintaining pump can cause injury to personnel from accidental handling of liquids that may harm skin or clothing, or fire hazard risks from flammable liquids, or injury from high pressure fluid jets.</p> | |

| | |
|---|---------------|
|  | DANGER |
| <p>BEFORE working on equipment, make sure all power to equipment is disconnected and locked-out.</p> | |

H.1 GENERAL COMMENTS

NOTE: Part number identifiers (IDP's) contained within parenthesis such as (9) refer to circled numbers shown on assembly drawing, figure 3 and Table 2.

H.2 TOOLS REQUIRED

Procedures described in this manual require common mechanics hand tools, a torque wrench, dial indicator and suitable lifting device (such as) slings, straps, etc.

H.3 DISASSEMBLY PROCEDURES – See assembly drawing

SPECIAL NOTE: To service mechanical seal and ball bearings **ONLY** perform H.3, Steps 1, 7, 8 and 9 and 10 and H.4, Steps 8, 9, 10, 11 and 12.



CAUTION

Fluid leakage from disassembly of pump may make floor slippery and cause personal injury.

1. Close suction and discharge piping to pump and disconnect piping. Remove seal piping (71). Remove drain plugs (67), and drain unit. Remove pump from driver, coupling and base plate. Remove coupling hub and key (31).
2. Remove bolts (4) and inlet head (2). Remove Gasket (9) from inlet head (2).
3. Remove spiral rings (8) from grooves in case (1).
4. Remove thrust cage (29), then tube (26) from either cage (29) or inlet housing (24).
5. Remove idler balance piston housings (23) from suction idlers (21).
6. Remove suction idlers (21) by unscrewing them from inlet end of pump. Remove remaining idlers (35) from housings (24), (50), by rotating power rotor (63) in a counter-clockwise direction.

CAUTION

Do not permit idlers (21), (35), to drop as they emerge from housings (24), (50).

7. Remove bolts (47) and bearing retainer (43) from inboard cover (46).
8. Remove assembled power rotor (63). Removal of power rotor (63) includes removal of Truarc rings (42), ball bearing (49), seal adapter (48), spacer (38) and mechanical seal (25).
9. Disassemble power rotor (63) as follows:
 - a. Using a flat nosed tool, such as a screw driver, remove Truarc rings (42) located on both sides of ball bearing (49) from their grooves in power rotor (63).
 - b. Sealed ball bearing is assembled to power rotor (63) with light press fit. Ball bearing (49) may be removed by using a bearing puller or a vertical arbor press. When using press, two pieces of key stock are to be placed through openings of mechanical seal seat adapter (48) underneath ball bearing (49) on both sides of power rotor shaft. Key stock should be long enough to support power rotor (63) as it is placed in press. Press ram is to be positioned against power rotor (63) coupling end face. Gently press power rotor (63) through ball bearing (49). Ensure power rotor (63) does not fall to floor once ball bearing (49) is off of its diameter.
 - c. Remove seal seat adapter (48) from power rotor (63), then remove mechanical seal stationary seat from seal seat adapter (48). Loosen set screws on mechanical seal rotating assembly body and remove from power rotor (63). Remove spacer (38) from the power rotor (63).
10. Remove Gasket (84) from inboard end cover (46).
11. Remove bolts (4) and inboard cover (46) from case (1).
12. Remove Gasket (9) from inboard cover (46).
13. Remove Truarc ring (101) from retainer (100) and retainer (100) from case (1).
14. Remove balance piston housing (78) from case (1) and O-ring (28) from balance piston housing (78).

15. Remove idler stop (80) from balance piston housing (78) by removing bolts (81). Remove pin (73) from idler stop (80). Remove floating balance piston bushing (79) from balance piston housing (78).
16. Remove stop pin (6) and Dyna seal (7) from case (1).
17. Remove housing (50) from case (1) and O-ring (28) from housing (50).

CAUTION

Do not permit housing (50) to drop as it is removed from pump.

18. Remove aligning vent pins (77) from housing (24 or 50).
19. Remove housing (24) from case (1).

CAUTION

Do not permit housing (24) to drop as it is removed from pump.

H.4 PUMP ASSEMBLY PROCEDURE

Note: Bolts (81) have Nylok in threads. Torque stated on assembly drawing for bolt (81) does not include additional torque required to install fasteners containing Nylok inserts. Torque required for first application is much higher than it is for subsequent applications. To ensure required preload on a Nylok fastener is achieved for each application, the following procedure is mandatory assembly practice.

1. Using a suitable torque wrench, install fastener in mating piece until Nylok insert is completely engaged. Note torque required.
2. Add torque measured in step 1. to torque value called for on assembly drawing.
3. Complete by tightening fastener to torque value determined in 2. above.

Note: Prior to reassembly of pump, all parts should be cleaned and inspected for nicks and burrs. Replace all worn or damaged parts. Imo Pump recommends replacement of all O-rings (28), gaskets (9, 84), Dyna Seal (7), mechanical seal (25) and ball bearing (49) when these parts are disturbed from their previously installed positions. Coat all parts with light lubricating oil to assist in assembly.

1. Install O-ring (28) in groove of discharge housing (50).
2. Install discharge housing (50) in pump case (1), from suction end, aligning groove on OD of housing (24) to stop pin hole in case (1). Install stop pin (6) with Dyna Seal (7) in case (1).
3. Install vent pins (77) in end of inlet housing (73) opposite O-ring.
4. Install inlet housing (24) in case (1), ensuring that vent pins (77) engage holes in discharge housing (50).
5. Install pin (73) in outboard end of discharge housing (50).
6. Install balance piston (79) into balance piston housing (78). Install idler stop (80) on balance piston housing (78) with cap screws (81). Torque cap screws to value on assembly drawing. Install O-rings (28) on balance piston housing (78).
7. Install balance piston housing (78) into case (1) being sure that pin (073) in discharge housing (50) engages pin hole in idler stop (80).
8. Install segmented spacer (100) in groove in case (1), holding in it with snap ring (101).
9. Install Inboard cover (46) on case (1) using bolts (4). Torque bolts to proper value on assembly drawing.

10. Assemble power rotor (63) and mechanical seal (25) as follows (see seal insert Figure 2).
 - a. Install O-ring (2) in groove of mechanical seal (25) stationary seat (1). Install mechanical stationary seat (1) in seal spacer (48) ensuring that spring pin (83) is properly positioned to engage slot in seal seat.
 - b. Install seal spacer (38) on power rotor (63).
 - c. Install mechanical seal (25) rotating assembly (3) on power rotor (63) next to spacer (38). Tighten set screws (3E).
 - d. Wipe mechanical seal rotating and stationary faces with a clean, lint free cloth before assembling faces together.
 - e. Install assembled bearing spacer (48), with stationary seat (1), to power rotor shaft next to mechanical seal rotating face.
 - f. Install inner Truarc ring (42) in groove of power rotor (63).
 - g. Press bearing (49) on power rotor (63), pressing only on inner race of ball bearing (49) until it is located next to inner Truarc ring (42).
 - h. Install outer Truarc ring (42) in groove of power rotor (63).
11. Install gasket (84) in seal bore of inboard cover (46).
12. Install assembled power rotor (63) in pump, centering all parts as they enter inboard cover (46). Align one of openings in spacer (48) over drain in inboard cover (46).
13. Install bearing retainer (43) on inboard cover (46) using bolts (47). Torque bolts to values indicated on assembly drawing.
14. Install idlers (35, 21) into housings by meshing threads with power rotor thread and screwing them into housing idler bores.
15. Install idler balance piston housings (23) to ends of suction idlers (21).
16. Install pin (26) in inlet housing (24).
17. Install thrust cage (29) in pump case (1), ensuring that pin hole in thrust cage (29) engages pin (26) in suction housing (24).
18. Install retaining rings (8) in pump case (1).
19. Install gasket (9) on inlet head (2).
20. Install inlet head (2) using bolts (4). Torque bolts to values indicated on assembly drawing.
21. Install seal piping (71) and drain plug (67).

Note: Inlet head (2) can be rotated and repositioned in 90° increments to suit suction piping. To change inlet position, disconnect seal piping (71), remove bolts (4) and rotate inlet head to desired position. Install bolts (4) and torque to proper values indicated on assembly drawing. Reconnect seal piping (71).
22. Install coupling hub key (31). Install and align pump and driver as specified in General Instruction Manual, CA-1.

H.5 SPECIAL TESTING INSTRUCTIONS

After pump has been reassembled with a major kit, it is recommended that a break-in test be performed to allow idlers to polish into babbitt housing bores. For this test, pump should be run to maximum required working pressure starting from 300 psig, in 200 psig increments, holding each pressure for five minutes.

I. TROUBLESHOOTING

For assistance with troubleshooting see General Instruction Manual, CA-1.

J. FIELD AND FACTORY SERVICE AND PARTS

Imo Pump maintains a staff of trained service personnel that can provide pump installation, pump start-up, maintenance/overhaul and troubleshooting supervision as well as installation and maintenance training.

Our factories provide maintenance as well as overhaul and test facilities in the event user prefers to return pumps for inspection or overhaul. Pumps that have been factory-overhauled are normally tested and warranted "as-new" for a period of one year from date of shipment. For either field service or factory overhaul assistance, contact your local Imo Distributor or the Technical/Customer Service Department in Monroe, NC, USA.

Most pumps have repair kits available. Minor Repair Kits are used to repair leaking seals, bad bearings and/or for re-assembly after pump tear-down. They include (as applicable) pump shaft seals, packing, all gaskets/O-rings and bearings. Major Repair Kits are sufficient to rebuild completely worn-out pumps to "as-new" condition. They include all parts found in Minor Repair Kits plus all major internal parts subject to wear. Since kits have all necessary parts, it is preferred that they be purchased rather than selecting individual parts. When parts are individually selected from Parts List, some needed components are often overlooked. In addition, mixing worn or used parts with new parts risks rapid wear and shortened service life from new parts.




Figure 2 – Borg Warner Type Q Mechanical Seal or Crane Type 8-1 Mechanical Seal




Figure 2 – Assembly Drawing



A Colfax Business Unit

Imo Pump

1710 Airport Road

PO Box 5020

Monroe, NC USA

28111.5020

tel 704.289.6511

fax 704.289.9273

email Imo.Pump@ColfaxCorp.com

web www.imopump.com

Manufacturing under ISO 9001:2000 Quality Management Systems

© 2005 Imo Pump All rights reserved.

Instructions D12DZ-250 (R-0) SRM 00078